























Для моделей VM, BMM, CM, CMM








 A1	 A2	 A3	 A4	 A5
 A6	 A7	 A8	 A9	 A10
 A11	 A12	 A13	 A14	 A15
 A16	 A17	 A18	 A19	





ST4X40=8 ST4X12=28
ST4X10=4



M4X40=4 M4X16=22





9




2





3




8




7




4




5




A




B




C



D



E



F

6